Looking after filament



Keep it dry

Store spools in sealed bags or dry boxes with desiccant. Damp filament prints with bubbles and stringing.



Don't let it unwind

A loose end tangles on the spool and can jam the printer halfway through a print.



Clip the end in

Push the end through a hole in the spool's side, or clip it, every time you take a spool off.

POWERED BY

SimplyPrint